

# <u>Crane Terminology</u>

# **Abnormal Operating Conditions:**

Environmental conditions that are unfavorable, harmful or detrimental to or for the operation of a hoist, such as excessively high (over 100 F.) or low (below 0 F.) ambient temperatures, corrosive fumes, dust laden or moisture laden atmospheres, and hazardous locations.

# Adjustable or Variable Voltage:

A method of control by which the motor supply voltage can be adjusted.

#### **Automatic Crane:**

A crane which when activated operates through a preset cycle or cycles.

# Auxiliary Hoist:

A supplemental hoisting unit, usually designed to handle lighter loads at a higher speed than the main hoist.

# Auxiliary Girder (Outrigger):

A girder arranged parallel to the main girder for supporting the platform, motor base, operator's cab, control panels, etc., to reduce the torsional forces such load would otherwise impose on the main girder.

# Bearing Life Expectancy:

The L-10 life of an anti-friction bearing is the minimum expected life, hours, of 90 percent of a group of bearings, which are operating at a given speed and loading. The average expected life of the bearings is approximately five times the L-10 life.

## BHN:

Brinell hardness number, measurement of material hardness.

10200 Jacksboro Hwy Ft. Worth, Texas 76135 Phone 817.237.7700 Fax 817.237.2777



#### **Box Section:**

The rectangular cross section of girders, trucks or other members enclosed on four sides.

#### Brake:

A device, other than a motor, used for retarding or stopping motion by friction or power means.

### **Branch Circuit:**

The circuit conductors between the final overcurrent device protecting the circuit and the outlet(s).

#### Bridge:

That part of an overhead crane consisting of girders, trucks, end ties, walkway and drive mechanism which carries the trolley and travels in a direction parallel to the runway.

### **Bridge Conductors:**

The electrical conductors located along the bridge structure of a crane to provide power to the trolley.

### Bridge Rail:

The rail supported by the bridge girders on which the trolley travels.

### Bumper (Buffer):

An energy absorbing device for reducing impact when a moving crane or trolley reaches the end of its Permitted travel, or when two moving cranes or trolleys come into contact.

### Cab-Operated Crane:

A crane controlled by an operator in a cab located on the bridge or trolley.



#### Camber:

The slight upward vertical curve given to girders to compensate partially for deflection due to hook load and weight of the crane.

# Capacity:

The maximum rated load (in tons) which a crane is designed to handle

#### Clearance:

Minimum distance from the extremity of a crane to the nearest obstruction.

#### CMAA:

Crane manufacturers Association of America, Inc. (formerly EOCI - Electric Overhead Crane Institute).

## **Collectors:**

Contacting devices for collecting current from the runway or bridge conductors. The mainline collectors are mounted on the bridge to transmit current from the runway conductors, and the trolley collector are mounted on the trolley to transmit current from the bridge conductors.

## Contactor, Magnetic:

An electro-magnetic device for opening and closing an electric power circuit.

#### Controller:

A device for regulating in a predetermined way the power delivered to the motor or other equipment.

## Counter-torque:

A method of control by which the motor is reversed to develop power to the opposite direction.

10200 Jacksboro Hwy Ft. Worth, Texas 76135 Phone 817.237.7700 Fax 817.237.2777



# Cover Plate:

The top or bottom plate of a box girder.

### **Cross Shaft:**

The shaft extending across the bridge, used to transmit torque from the motor to bridge drive wheels.

#### **Cushioned Start:**

An electrical or mechanical method for reducing the rate of acceleration of a travel motion.

#### Dead Loads:

The loads on a structure, which remain in a fixed position relative to the structure. On a crane bridge such loads include the girders, footwalk, cross shaft, drive units, panels, etc.

#### **Deflection:**

Displacement due to bending or twisting in a vertical or lateral plane, caused by the imposed live and dead loads.

# Diaphragm:

A plate or partition between the opposite parts of a member serving a definite purpose in the structural design of the member.

#### Drive Girder:

The girder on which the bridge drive machinery is mounted.



# Dummy Cab:

An operator's compartment or platform on a pendant or radio controlled crane, having no permanently mounted electrical controls, in which an operator may ride while controlling the crane.

## Dynamic Lowering:

A method of control by which the hoist motor is so connected in the lowering direction, that when it is overhauled by the load, it acts as generator and forces current either through the resistors or back into the line.

# **Eddy-Current Braking:**

A method on control by which the motor drives through an electrical induction load brake.

## Efficiency of Gearing and Sheaves:

The percentage of force transmitted through these components that are not lost to friction.

## Electric Overhead Traveling Crane:

An electrically operated machine for lifting, lowering and transporting loads, consisting of a movable bridge carrying a fixed or movable hoisting mechanism and traveling on an overhead runway structure.

## **Electrical Braking System:**

A method of controlling crane motor speed when in an overhauling condition, without the use of friction braking.

### Enclosed conductor(s):

A conductor or group of conductors substantially enclosed to prevent accidental contact.

10200 Jacksboro Hwy Ft. Worth, Texas 76135 Phone 817.237.7700 Fax 817.237.2777



#### **Enclosure:**

A housing to contain electrical components, usually specified by a NEMA classification number.

## End approach:

The minimum horizontal distance, parallel to the runway, between the outermost extremities of the crane and the centerline of the hook.

#### End tie:

A structural member other than the end truck which connects the ends fo the girders to maintain the squareness of the bridge.

## **Endtruck:**

The unit consisting of the truck frame, wheels, bearings, axles, etc., which supports the bridge girders.

#### Fail-safe:

A provision designed to automatically stop or safely control any motion in which a malfunction occurs.

# Field wiring:

The wiring required after erection of the crane.

### Fixed axle:

An axle which is fixed in the truck and on which the wheel revolves.

### Floor-Operated Crane:

A crane which is pendant controlled by an operator on the floor or an independent platform.

10200 Jacksboro Hwy Ft. Worth, Texas 76135 Phone 817.237.7700 Fax 817.237.2777



#### Footwalk:

The walkway with handrail and toeboards, attached to the bridge or trolley for access purposes.

# **Gantry Crane:**

A crane similar to an overhead crane except that the bridge for carrying the trolley or trolleys is rigidly supported

on two or more legs running on fixed rails or other runway.

### Girders:

The principal horizontal beams of the crane bridge which supports the trolley and is supported by the end trucks.

#### Ground Fault:

An accidental conducting connection between the electrical circuit or equipment and the earth or some conducting body that serves in place of the earth.

#### Hoist:

A machinery unit that is used for lifting and lowering a load.

# Holding Brake:

A brake that automatically prevents motion when power is off.

## Hook Approach:

The minimum horizontal distance between the center of the runway rail and the hook.



# Hydraulic Brake:

A brake that provides retarding or stopping motion by hydraulic means.

#### **Idler Sheave:**

A sheave used to equalize tension in opposite parts of a rope. Because of its slight movement, it is not termed a running sheave.

## Impact Allowance:

Additional hook load assumed to result from the dynamic effect of the live load.

## **Industrial Duty Crane:**

Service classification covered by CMAA Specification No. 70, 'Specifications for Electric Overhead Traveling Cranes'.

#### **Insulation Class:**

Motor winding insulation rating which indicates its ability to withstand heat and moisture.

## Inverter(Variable Frequency Drive):

A method of control by which the fixed line voltage and frequency is changed to a three-phase system with infinitely variable voltage and frequency.

#### **K.S.I.:**

Kips per square inch, measurement of stress intensity.

## Kip:

A unit of force, equivalent to 1000 pounds.

10200 Jacksboro Hwy Ft. Worth, Texas 76135 Phone 817.237.7700 Fax 817.237.2777



#### Knee Brace:

The diagonal structural member joining the building column and roof truss.

### **Lateral Forces:**

Horizontal forces perpendicular to the axis of the member being considered.

#### Lift:

Maximum safe vertical distance through which the hook, magnet, or bucket can move.

# Lift Cycle:

Single lifting and lowering motion (with or without load)

## Lifting Devices:

Buckets, magnets, grabs and other supplemental devices, the weight of which is to be considered part of the rated load, used for ease in handling certain types of loads.

#### Limit Switch:

A device designed to cut off the power automatically at or near the limit of travel for the crane motion.

#### Line Contactor:

A contactor to disconnect power from the supply lines.

### Live Load:

A load which moves relative to the structure under consideration.



#### Load Block:

The assembly of hook, swivel, bearing, sheaves, pins and frame suspended by the hoisting ropes.

# **Load Carrying Part:**

Any part of the crane in which the induced stress is influenced by the load on the hook.

## Load Cycle:

One lift cycle with load plus one lift cycle without load.

## Longitudinal Stiffeners:

Horizontal members attached to the web of the bridge girder to prevent web buckling.

## Magnetic Control:

A means of controlling direction and speed by using magnetic contactors and relays.

### Main Line Contactor:

A magnetic contactor used in the incoming power circuit from the main line collectors.

## Main Line Disconnect Switch:

A manual switch which breaks the power lines leading from the main line collectors.

### Manual-Magnetic Disconnect Switch:

A power disconnecting means consisting of a magnetic contactor that can be operated by remote pushbutton and can be manually operated by a handle on the switch.

10200 Jacksboro Hwy Ft. Worth, Texas 76135 Phone 817.237.7700 Fax 817.237.2777



#### Master Switch:

A manually operated device which serves to govern the operation of contactors and auxiliary devices of an electric control.

# Match Marking:

Identification of non-interchangeable parts for re-assembly after shipment.

#### Mechanical Load Brake:

An automatic type of friction brake used for controlling loads in the lowering direction. This unidirectional device requires torque from the motor to lower a load but does not impose additional load on the motor when lifting a load.

#### Mean Effective Load:

A load used in durability calculations accounting for both maximum and minimum loads.

### Mill Duty Crane:

Service classification covered by AISE Standard No. 6, Specification for Electric Overhead Traveling Cranes for Steel Mill Service.

# Multiple Girder Crane:

A crane which has two or more girders for supporting the live load.

#### Non-coasting Mechanical Drive:

A drive with coasting characteristics such that it will stop the motion within a distance in feet equal to 10 percent of the rated speed in feet per minute when traveling at rated speed with rated load.

10200 Jacksboro Hwy Ft. Worth, Texas 76135 Phone 817.237.7700 Fax 817.237.2777



# Operator's Cab:

The operator's compartment from which movements of the crane are controlled. To be specified by the manufacturer as open, having only sides or a railing around the operator, or enclosed, complete with roof, windows, etc.

#### Overload:

Any load greater than the rated load.

### Overload Limit Device:

Refer to Section 4.3 for a complete definition.

## Overload Protection (Overcurrent):

A device operative on excessive current to cause and maintain the interruption or reduction of current flow to the equipment governed.

#### Pendant Pushbutton Station:

Means suspended from the crane operating the controllers from the floor or other level beneath the crane.

### Pitch Diameter (Rope):

Distance through the center of a drum or sheave from center to center of a rope passed about the periphery.

### Plain Reversing Control:

A reversing control which has identical characteristics for both directions of motor rotation.



# Plugging:

A control function which accomplishes braking by reversing the motor line voltage polarity or phase sequence.

#### **Protective Panel:**

An assembly containing overload and under voltage protection for all crane motions.

## Qualified:

A person who, by possession of a recognized degree, certificate of professional standing or who by extensive knowledge, training, and experience, has successfully demonstrated the ability to solve or resolve problems relating to the subject matter and work.

#### Rated Load:

The maximum load which the crane is designed to handle safely as designated by the manufacturer.

### Regenerative Braking:

A method of controlling speed in which electrical energy generated by the motor is fed back into the power system.

## Regulated Speed:

A function which tends to maintain constant motor speed for any load for a given speed setting of the controller.

### Remote Operated Crane:

A crane controlled by an operator not in a pulpit or in the cab attached to the crane, by any method other than pendant or rope control.

10200 Jacksboro Hwy Ft. Worth, Texas 76135 Phone 817.237.7700 Fax 817.237.2777



# **Resistor Rating:**

Rating established by NEMA which classifies resistors according to percent of full load current on first point and duty cycle.

## Rotating Axle:

An axle which rotates with the wheel.

## **Running Sheave:**

A sheave which rotates as the hook is raised or lowered.

## Runway:

The rails, beams, brackets and framework on which the crane operates.

## **Runway Conductors:**

The main conductors mounted on or parallel to the runway which supplies current to the crane.

# Runway Rail:

The rail supported by the runway beams on which the bridge travels.

#### Shall:

This word indicates that adherence to the particular requirement is necessary in order to conform to the specification.

#### Sheave:

A grooved wheel or pulley used with a rope or chain to change direction and point of application of a pulling force.

10200 Jacksboro Hwy Ft. Worth, Texas 76135 Phone 817.237.7700 Fax 817.237.2777



#### Should:

This word indicates that the requirement is a recommendation, the advisability of which depends on the facts in each situation.

#### Skeleton Cab:

Same as dummy cab.

## **Skewing Forces:**

Lateral forces on the bridge truck wheels caused by the bridge girders not running perpendicular to the runways. Some normal skewing occurs in all bridges.

## Span:

The horizontal distance center-to-center of runway rails.

#### **Static Control:**

A method of switching electrical circuits without the use of contacts.

## **Stepless Control:**

A type of control system with infinite speed control between minimum speed and full speed.

## **Stepped Control:**

Atype of control system with fixed speed points.

## Stop:

A device to limit travel of a trolley or crane bridge. This device normally is attached to a fixed structure and normally does not have energy absorbing ability.

10200 Jacksboro Hwy Ft. Worth, Texas 76135 Phone 817.237.7700 Fax 817.237.2777



# Strength, Average Ultimate:

The average	tensile force	per unit of	cross sect	tions area	required 1	to rupture	the material as	s determined	. by
test.									

# Sweep:

Maximum lateral deviation from straightness of a structural member, measured at right angles to the Y-Yaxis.

### TEFC:

Totally enclosed fan cooled.

### **TENV:**

Totally enclosed non-ventilated.

## Torque, Full Load (Motor):

The torque produced by a motor operating at its rated horsepower and speed.

### Torsional Box Girder:

Girder in which the trolley rail is located over one web.

### **Torsional Forces:**

Forces which can cause twisting of a member.

## Trolley:

The unit carrying the hoisting mechanism which travels on the bridge rails.

10200 Jacksboro Hwy Ft. Worth, Texas 76135 Phone 817.237.7700 Fax 817.237.2777



# **Trolley Frame:**

The basic structure of the trolley on which are mounted the hoisting and traversing mechanisms.

# Two Blocking:

Condition under which the load block or load suspended from the hook becomes jammed against the crane structure preventing further winding up of the hoist drum.

# **Undervoltage Protection:**

A device operative on the reduction or failure of voltage to cause and maintain the interruption of power in the main circuit.

# Variable Frequency:

A method of control by which the motor supply voltage and frequency can be adjusted.

# Voltage Drop:

The loss of voltage in an electric conductor between supply tap and load tap.

### Web Plate:

The vertical plate connecting the upper and lower flanges or cover plates of a girder.

### Wheelbase:

Distance from center-to-center of outermost wheels.

## Wheel Load:

The load without impact on any wheel with the trolley and lifted load (rated capacity) positioned on the bridge to drive maximum loading

10200 Jacksboro Hwy Ft. Worth, Texas 76135 Phone 817.237.7700 Fax 817.237.2777